ユーザーガイド

製品紹介と応用範囲

この製品はPS5Dual Senseオリジナルコントローラーに適しており、TurboとMacroを搭載し、オリジナルコントローラーをより多くの機能で拡張します。

製品外観



注：画像はあくまでも参考であり、現物限りである。

製品の機能

*標準ボタン：M1、M2、M3、M4、ON、Turbo、Macro、Clear 合計8ボタン。
*TYPE C USBケーブル接続対応できます。
*PS5 Dual Senseオリジナルコントローラをサポートします。
*RGB LEDカラーインジケータにより、異なるステータスを表示できます。
*PCのUSBでオンラインアップグレードが可能で、ファームウェアアップグレードで最適化できます。

PS5プラットフォームの機能

P5のバックボタンをPS5 Dual Senseコントローラーに接続し、P5のバックボタンをケーブルでPS5本体に接続すると、PS5本体で動作しているすべてのゲームを操作することができます。

PC WINDOWSプラットフォームの機能

P5のバックボタンをPS5 Dual Senseコントローラに接続した後、P5のバックボタンをデータケーブルでPC Windowsコンピュータに接続すると、PS5 Dual Senseで動作するすべてのPC Windowsゲームを操作することができます。（対応システムは、PS5 Dual Senseコントローラーがサポートする WINDOWSシステムです）。

製品使用

*このバックキーはPS5コンソールとの接続にUSB有線モードを使用するため、使用前にPS5コンソールのUSB接続機能を開いてください、設定方法：（設定-周辺機器-コントローラ（一般）-接続方法-USB有線接続を使用）。

* このバックキーに付属しているTYPE CオスコネクタをPS5コントローラのTYPEC充電ポートに挿入し、このバックキーをPS5コントローラのヘッドホンホールのプラスチックシェルに嵌め込みます。組み立てた状態は以下の通り。
*PS5コントローラに付属のTYPECケーブルの一端をTYPECホルダーに、もう一端をPS5コントローラに接続する。
*接続が成功すると、バックボタンのランプが自動的に青色に点灯し、バックボタンを正常に使用できるようになります。
*再度バックボタンのONボタンを押すと、青いランプが消えます。 この時、背面ボタンは動作せず、PS5コントローラーは正常に使用できます。
注意：接続完了後、バックボタンのインジケーターランプが点滅している場合は、バックボタンが青色で常時点灯するまで電源を入れ直す必要があります。

マッピング機能

*Macroボタンを押すと、緑のランプが点滅し、マッピング設定モードに入ります。
*コントローラのファンクションキーを押しながらバックキーを押すと、そのファンクションキーがバックキーにマッピングされます。
*もう一度Macroを押すと、マッピング設定モードを終了します。 この時、青ランプは常時点灯しており、本製品は正常に動作します。
*Macroボタンを押してマッピングモードに入った後、複数のバックキーマッピングを行うことができます。 例えば、Xを押してからM1を押します。
続けてL2を押してからM2を押します。 マッピングが完了したら、もう一度Macroを押してマッピング設定モードを終了します。 この時点では、M1がXキー、M2がL2キーに対応しています。
*マッピングとキーコンビネーションをクリアするには：Macroボタンを約3秒間長押しすると、緑のライトが遅い点滅から速い点滅に変わり、その後青いライトが永久に点灯したら、すべてのマッピングとキーコンビネーション設定をクリアすることができます。
注：コントローラのすべてのボタンは、MICスイッチボタンを除いてマッピングできます。

キーコンビネーション・マッピング機能

*Macroボタンを押すと緑のランプが点滅し、マッピング設定モードに入ります。
*コントローラの複数のファンクションボタンを交互に押してから、バックボタンを押す。
*Macroボタンをもう一度押すと、マッピング設定モードを終了します。 青いランプは常に点灯しています。 このバックボタンを押すと、コントローラの複数のファンクションボタンを同時に押したのと同じ状態になります。
*マッピングとキーコンビネーションのクリア：Macroボタンを約3秒間長押しすると、緑のランプが遅い点滅から速い点滅に変わり、その後青いランプが常時点灯したら、すべてのマッピングとキーコンビネーション設定をクリアすることができます。
注：コントローラのすべてのボタンは、MICスイッチボタンを除いてマッピングできます。

Turbo連発機能

*Turboボタンを押すと赤いランプが点滅し、連発設定モードになります。
*コントローラのファンクションボタン（バックボタンを含む）を順番に押して、連発機能を設定します。
*連発設定モードを終了するには、もう一度Turboボタンを押します。 青いランプが点灯します。 ユーザーが設定したキーが連発機能を持つようになります。
*Turboに設定できるボタンは以下の通りです。
ハンドル：↑、↓、←、→、╳、○、□、△、L1、L2、L3、R1、R2、R3。
バッククランプ：M1、M2、M3、M4。
*連続クリア：Turboボタンを約3秒間長押しすると、赤いライトが遅い点滅から速い点滅に変わり、その後青いライトが常に点灯したら、すべての連続設定をクリアすることができます。
*Clearボタンを3秒間長押しすると、MacroとTurboの全設定が同時にクリアされます。

製品のアップグレード

*公式フォーラム（https://forum.beloader.com）から最新のアップグレードツールソフトウェアとアップグレードファームウェアをダウンロードし、コンピュータのディスクに解凍します。
*背面ボタンのONボタンを長押し続け、データケーブルを通して背面ボタンをWINDOWES PCのUSBポートに差し込んだ後、ONボタンを離します。
*Microsoft Edgeブラウザでアップグレードフォルダ index.html を開き、次の通りします：
背面ボタンのONボタンを押し続け、適合するUSBケーブルでPCのUSBポートに接続すると、インジケータランプがシアン色に点灯します。



こちらのインターフェースボタンをクリック

（图1）



1，こちらのインターフェースボタンをクリック

2，こちらのインターフェースボタンをクリック

（图2）



1，こちらのインターフェイスのボタンをクリックして、ファームウェアを選択します。

2,こちらのインターフェースボタンをクリックして、アップグレードします。

（图3）



アップグレードが完了したら、、対応するバージョン番号が表示される

アップグレード完了したら、、プログレスバーがフルフレームで表示される

（图4）

User Manual

Product Brief

This product is suitable for PS5 Dual Sense original controller, with Turbo and Macro to extend the original controller more features.

Product Photo



Product Feature

* Standard Buttons: M1, M2, M3, M4, ON, Turbo, Macro, Clear, total 8 buttons.
* It support TYPE-C USB data cable connection.
* It support PS5 Dual Sense original controller.
* With RGB LED color indicator, can indicate different working states.
* The product can be upgraded online by PC USB, can be optimized by firmware upgrade.

PS5 Function:

Install the back paddle on the PS5 Dual Sense controller, connect the back paddle with PS5 console through the data cable, then you can control all PS5 games running on the console.

PC WINDOWS Function

Install the back paddle on the PS5 Dual Sense controller, connect the back paddle with PC WINDOWS through the data cable, then you can use PS5 Dual Sense control all games running on the PC. (The supported systems are WINDOWS systems which supported by PS5 Dual Sense controller)

Product Usage

* The back paddle uses USB wired mode to connect the PS5 console, please enable the USB connection function of the PS5 console before use, setting method: **(Settings -- Peripherals -- Controller (general) -- Connection method -- Use USB wired connection).**
* Insert the TYPE C male head of the back paddle into the TYPE C charging port of the PS5 controller, and then fasten the back paddle into the plastic shell of the headphone hole of the PS5 controller, as shown in the following picture after assembly.
* Connect one end of the TYPE C data cable to the back paddle TYPE C seat, and connect the other end to the PS5 console.
* If the back paddle is successfully connected, the indicator automatically turns blue, and the back paddle can be used normally.
* If the user presses the ON key on the back paddle again, the blue light goes out. At this time, the back paddle does not work, and the PS5 controller is used normally.

Remark: After the connection is complete, if the back paddle indicator blinks, the back paddle needs to be powered on again until the indicator is blue.

Mapping Function

* Press the Macro button, the green light blinks, and you enter mapping setup mode.
* When a user presses a function key on the controller and then presses a back paddle key, the function key is mapped to the back key.
* Press the Macro button again to exit mapping setup mode. At this time, the blue light is on, and the product can work normally.
* When the user enters mapping mode by pressing the Macro button, multiple back key mappings can be performed. For example, press the X, then press the M1; continue to press the L2, then press the M2. After the mapping is complete, press the Macro to exit the mapping setup mode. In this time, M1 corresponds to the X key and M2 corresponds to the L2 key.
* Clear mapping and combination keys: Press and hold the Macro key for about 3 seconds, the green light changes from slow blinking to fast blinking, and then the blue light is on, which means that all mapping and combination key Settings are cleared.

Remark: All buttons of the controller can be mapped except the MIC On/Off button.

Combination key mapping function

* Press the Macro button, the green light blinks, and you enter mapping setup mode.
* The user alternately presses multiple function keys on the controller and then presses a back paddle key.
* Press the Macro button again to exit mapping setup mode. At this time, the blue light is on. When a user presses this back key, it is equivalent to pressing multiple controller function keys at the same time.
* Clear mapping and combination keys: Press and hold the Macro key for about 3 seconds, the green light changes from slow blinking to fast blinking, and then the blue light is on, which means that all mapping and combination key Settings are cleared.

Remark: All buttons of the controller can be mapped except the MIC On/Off button.

Turbo Continuous Shooting Function

* Press the Turbo button, and the red light blinks to enter the continuous shooting setting mode.
* The user presses one or more function keys (including the back paddle key) on the controller one by one to set these keys to have the continuous shooting function.
* Press the Turbo button again to exit the continuous shooting setting mode. At this time, the blue light is on. The key set by the user has the function of continuous shooting.
* The keys which can be set Turbo as follows:

Controller keys: ↑, ↓, ←, →, ×, ○, □, △, L1, L2, L3, R1, R2, R3.
Back paddle keys: M1, M2, M3, M4.

* Clear the Continuous Shooting function: Press and hold the Turbo key for about 3 seconds, if the red light changes from slow blinking to fast blinking, and then the blue light is on, it indicates that all continuous shooting Settings are cleared.
* Hold down the Clear key for 3 seconds to clear all Macro and Turbo Settings at the same time.

Product Upgrade

* From the official website (https://forum.beloader.com) to download the latest software and upgrade the firmware upgrade tool, and extract it to a computer disks and then unpack it.
* Hold down the ON button of the back paddle, insert the back paddle into the USB port of the WINDOWES PC through the data cable, and then release the ON button.
* Open the upgrade folder index.html with your Microsoft Edge browser, follow these steps: Hold down the back paddle ON button, connect it to the USB port of the Computer through the USB cable, and the indicator light shows cyan.



Click it

（图1）



1, click it

2, click it

(图2)



1, click it to choose the firmware

2, click it to upgrade

(图3）



The upgrade is complete, the version is displayed.

The upgrade completion progress bar is full.

（图4）